



- Voltage Notes:**
1. Pins 1 & 6 of 12AX7 = 200VDC
 2. Pins 3 & 8 of 12AX7 = 1.8VDC
 3. Pin 8 of 6V6 = 22VDC

Build Your Own Clone		
Tweed Royal		
Designed & Drawn by: K. Vanderhulls	Rev 1.0 11/03/2012	tekittlml